

PARTS LIST

for



COMMERCIAL GAS DRYER

MODELS
CSP2771KQ0



FOR CUSTOMER SATISFACTION ALWAYS USE
FACTORY SPECIFICATION PARTS




Whirlpool CORPORATION

Benton Harbor, Michigan.

LOWER CABINET AND FRONT PANEL PARTS

For Model: CSP2771KQ0

(White)




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

LOWER CABINET AND FRONT PANEL PARTS

For Model: CSP2771KQ0
(White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts (Located Behind Toe Panel)	17	8529757	Bracket, Burner	46	3388229	Retainer
	LIT8527892	Installation Instructions	18	233520	Washer, Thurst	47	3392905	Door, Rear
	LIT8527882	Wiring Diagram	19	297092	Clip (2)	48	694091	Screw, 8-18 x 3/8
	LIT8527886	Tech Sheet	20	690997	Tri-Ring	49	3392880	Door, Front
	LIT8527820	Service Parts List	21	3389247	Hinge And Pin (2)	51	3393081	Upper Front Panel
2	3393258	Screw, 10-16 x 1/2	22	3392914	Frame, Window	52	696144	Strike, Door
3	3390663	Screw, 10-16 x 1/2	23	3392915	Gasket, Window	53	3393933	Fastener
4	3391846	Clip, Front Panel (2)	24	3393657	Restrainer, Belt	54	718032	Screw, 8-18 x 3/4
5	3394881	Switch, Broken Belt	25	3398948	Wire, Jumper	56	8529853	Harness (Lower)
6	697773	Screw, 6-20 x 7/8	26	3389249	Nut, "U" (4)	56A	3390423	Plug, Mult- Terminal
7	8310656	Cabinet, Lower	27	8538264	Motor Assembly (60 Hz.)	56B	717252	Receptacle
8	3392100	Foot, Dryer (Plastic) (4)	28	3394081	Wire, Jumper	57	3390735	Seal, Door
9	660658	Clamp, Motor (2)	29	3389627	Pulley 60 Hz	58	3392538	Catch, Door Assembly
10	3387374	Spring, Idler	30	3387610	Belt, Drive	59	8066120	Lever, Snap Switch
11	3389420	Retainer, Idler	31	3390902	Clip, Door Hinge (2)	60	3392906	Handle, Door
12	693995	Screw, 8-18 x 3/8	32	3387118	Bracket, Motor	61	697215	Panel, Toe
13	3388672	Pulley Assembly	33	3392186	Washer	64	3401797	Burner Assembly 60 Hz. (Refer To Pages 10 & 11 for Further Breakdown)
14	3391915	Screw, 10-16 x 1	38	8283298	Jumper, Door Switch	65	3390647	Screw, 8-18 x 1/2
15	3392918	Window (Not Shown Part 3396122, Window Pack. Includes Illus. 15 & 23)	38A	717253	Plug, 2-Way	66	3401775	Valve, Gas (Complete) 60 Hz
16	3394081	Wire, Belt Switch	38B	3936144	Connector	67	3387561	Clamp, Pipe
			39	3388674	Bracket, Idler	68	3393909	Screw, 8-32 x 7/8
			40	3388600	Clip, Lint Duct	69	686590	Ignitor
			41	3406109	Door Switch Assembly	70	3387057	Screw, 8-18 x 3/8
			42	98129	Screw, 6-20 x 1-1/16			
			44	3387242	Seal, Front Panel			
			45	342055	Screw, 8-18 x 1/2			

OPTIONAL PARTS (NOT INCLUDED)




Illus. No.	Part No.	DESCRIPTION
Optional Parts Not Included		
Dryer Exhaust Kit (For Side & Bottom Venting)		
1	279818	Exhaust Kit
2	697750	Plug, Multivent
3	279731	4"- 90° Elbow
4	488729	Screw
5	3394331	Plate, Cover (Bottom Exhaust)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL AND SEPARATOR PARTS

For Model: CSP2771KQ0
(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROL PANEL AND SEPARATOR PARTS

For Model: CSP2771KQ0

(White)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Collar Harness	14	94614	Terminal	28	3390443	Retainer,
	8529858	Lower	15	8538333	Board-Shield (2)			Terminal
	8529849	Upper	16	3979254	Bracket,	29	489399	Screw, 8-32 x 5/16
2	3400000	Screw, 10-24 x 3/8			Switch Mounting	30	487871	Screw, 8-32 x 3/8
3	3391018	Tie, Cable	17	8530176	Switch,	31	3406197	A.C. In-Line
4	697776	Screw, 10-32 x 5/8			Clean Touch (2)			Filter
5	98139	Screw,	18	3979237	Lens Display	32	3401402	Power Cord
		8-32 x 5/16	19	3390189	Strain Relief	33	3401709	Jumper Wire,
6	385421	Funnel, Coin (2)	20	3401708	Wire, Ground			Ground
7	8529860	Harness, Switch	21	8539881	Jumper Wire	34	3955730	Harness,
8	3407165	Control Board (2)	22	3400500	Bolt,			Control to Display
9	3393909	Screw, 8-32 x 7/8			5-16/18 x 3/4	35	3955729	Harness, Wire
10	3954761	Plate,	23	3978853	Collar	40	8541016	Stacking Spacer
		Chute Adapter (2)	24	486529	Nut-Hex, 8-32	41	3401850	Harness, Gas
		(Includes	25	8528141	Display Board	41A	3403499	Connector,
		Illus. 6)			Assembly (2)			2-Position
11	3400029	Nut, 10-32 (6)			(Includes	41B	717252	Plug, 2-Way
12	3979246	Panel, Control			Illus. 40)	41C	3403498	Connector,
13	8528128	Insert & Button	26	2006252	Washer, Nylon			3-Position
		Overlay	27	3396795	Cover,	41D	697779	Plug, 3-Way
					Terminal Block			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER CABINET AND FRONT PANEL PARTS

For Model: CSP2771KQ0

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER CABINET AND FRONT PANEL PARTS

For Model: CSP2771KQ0

(White)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3390663	Screw, 10-16 x 1/2	25	3398948	Wire, Jumper	52	696144	Stike, Door
2	693995	Screw, 8-18 x 3/8	26	3389249	Nut, "U" (4)	54	718032	Screw, 8-18 x 3/4
3	3391846	Clip, Front Panel (2)	27	8538264	Motor Assembly 60 Hz.	55	3390647	Screw, 8-18 x 1/2
4	3391915	Screw, 10-16 x 1	28	3398948	Wire, Jumper	56	8529852	Harness (Upper)
5	3394881	Switch, Broken Belt	29	3389627	Pulley (60 Hz.)	56A	3390423	Plug, Multi-Terminal
6	697773	Screw, 6-20 x 7/8	30	3387610	Belt, Drive	56B	717252	Receptacle
7	8310656	Cabinet (Upper)	31	3390902	Clip, Door Hinge (2)	57	3390735	Seal, Door
8	689172	Foot, Dryer (Plastic) (2)	32	3387118	Bracket, Motor	58	3392538	Catch, Door Assembly
9	660658	Clamp, Motor (2)	33	8529757	Bracket, Burner	59	8066120	Lever, Snap Switch
10	3387374	Spring, Idler	36	3392186	Washer	60	3392906	Handle, Door
11	3389420	Retainer, Idler	37	3393258	Screw, 10-16 x 1/2	61	697215	Panel, Toe
12	3392915	Gasket, Window	38	8283298	Jumper, Door Switch	62	3389351	Top (Upper)
13	3388672	Pulley Assembly	38A	717253	Plug, 2-Way	63	3391018	Tie, Cable
14	63823	Cotter Pin	38B	3936144	Connector	65	3400523	Bolt, Security (Includes Illus. 14)
15	3392918	Window (Not Shown Part 3396122, Window Pack. Includes Illus. 12 & 15)	39	3388674	Bracket, Idler	66	3389233	Bushing
16	3394081	Wire, Belt Switch	40	3388600	Clip, Lint Duct	67	3401797	Burner Assembly 60 Hz.
18	233520	Washer, Thrust	41	3406109	Door Switch Assembly			(Refer To Pages 10 & 11 For Further Breakdown)
19	297092	Clip (2)	42	98129	Screw, 6-20 x 1-1/16	69	3401775	Valve, Gas (Complete) 60 Hz.
20	690997	Tri-Ring	44	3387242	Seal, Front Panel	70	3387561	Clamp, Pipe
21	3389247	Hinge And Pin (2)	45	342055	Screw, 8-18 x 1/2	71	3393909	Screw, 8-32 x 7/8
22	3392914	Frame, Window	46	3388229	Retainer	72	686590	Ignitor
23	3979115	Bracket, Angle	47	3392905	Door, Rear	73	3387057	Screw, 8-18 x 3/8
24	3393657	Restrainer, Belt	48	694091	Screw, 8-18 x 3/8			
			49	3392880	Door, Front			
			50	3393933	Fastener			
			51	3393081	Upper Front Panel			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER AND LOWER BULKHEAD PARTS

For Model: CSP2771KQ0

(White)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

UPPER AND LOWER BULKHEAD PARTS

For Model: CSP2771KQ0
(White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3399508	Shaft, R.H. Thread	16	3387709	Nut, 3/8-16 (L.H.)	43	3387230	Screw, 10-16 x 13/16
2	3357011	Screw, 10-16 x 1/2	17	3387809	Bulkhead, Rear	44	8530038	Housing, Blower
3	3390646	Screw, 8-18 x 5/16	18	3387459	Washer, Support	45	8530036	Lint Duct Assembly
4	90767	Screw, 8-18 x 3/8	19	3399509	Shaft, L.H. Thread	46	8066047	Funnel, Burner
5	3394346	Air Duct Assembly	20	690997	Ring, Tri	47	338906	Sensor, Radiant
6	697813	Seal, Outlet Housing	21	8536973	Roller, Support	48	3391912	Thermostat 255° (124°C)
7	697814	Seal, Drum Front	23	3394985	Housing, Outlet	52	697771	Cover, Blower (Includes Illus. Nos. 60 & 62)
8	3359452	Nut, 3/8 x 16 (R.H.)	25	8318215	Drum Complete	53	697693	Baffle, Drum (3)
9	8318486	Exhaust Pipe	26	97787	Screw, 11-16 x 3/4	54	697557	Bulkhead, Front
10	3388229	Clip, Exhaust	27	697694	Seal, Drum	58	8299979	Grill, Outlet
11	8066086	Drum Hole Plug	28	3394986	Spring, Lint Screen	59	3390719	Thermal Fuse
13	3390647	Screw, 8-18 x 1/2	31	487909	Screw, 8-15 x 1/2	60	697770	Seal, Cover Plate
			37	697772	Wheel, Blower	62	697769	Seal, Lint Duct
			38	3394984	Door, Lint Screen	64	3390721	Screen, Lint
			42	3387138	Thermostat, Internal-Bias			

OPTIONAL PARTS (NOT INCLUDED)

Illus. Part
No. No. DESCRIPTION

ACCESSORY PARTS

4392067 Kit,
Dryer Repair
8522199 Kit, Dryer
Vent Testing
285875 Kit, Security

PAINT, TOUCH-UP (1/2oz.)

72017 White

PAINT, PRESSURIZED SPRAY (12 oz.)

350930 White
350938 Primer, Grey

PAINT, BULK (1 qt.)


799344 White (Uncut)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

3401797 BURNER ASSEMBLY

For Model: CSP2771KQ0
(White)

USE WITH TYPE 1 – NATURAL, TYPE 2 – MIXED,
AND TYPE 4 – LIQUEFIED PROPANE AND BUTANE GASES



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

3401797 BURNER ASSEMBLY

For Model: CSP2771KQ0

(White)

USE WITH TYPE 1 – NATURAL, TYPE 2 – MIXED,
AND TYPE 4 – LIQUEFIED PROPANE AND BUTANE GASES

Illus. No.	Part No.	DESCRIPTION
1	3401797	Burner Assembly 60 Hz. (Type 1, 2 & 3) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8-32 x 5/8)
6	343641	Screw, 10-16 x 1/2
7	3389871	Base, Burner
8	3387057	Screw, 10-16 x 1/2 (3)
9		Orifice, Burner
	3397656	Type 1
	15775	Type 2
10	3401775	Valve, Gas 60 Hz. (Complete)
11	694421	Screw, 8-32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak, Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
20	239822	Plug, Pipe
21	3387224	Pipe, Gas Supply
22	697441	Valve & Union Shut-Off
23	3393767	Pipe, Tail
24	233076	Nut, Compression
25	3387561	Clamp, Pipe
26	3389889	Bracket, Support

Following Parts Not Illustrated

694572 Conversion Kit
(Type 1 and 2)
to Type (4) L.P.G.

BA – 133 – A

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST